

## GREEN CELL BATERIE PRO FUJITSU 4400MAH



Cena celkem:

**1 062 Kč**  
**(bez DPH: 878 Kč)**

Kód zboží:

BATRX4600

Part No.:

GCFS07

Záruka:

24 měsíců/6 měs. akku

Stav:

Nové zboží

## Popis

### Green Cell baterie pro Fujitsu 4400 mAh

Kompatibilní baterie **pro notebooky Fujitsu LifeBook**. Baterie je standardně vybavena ochranou proti přetížení, hlubokému vybití a přebití.

### ZÁKLADNÍ SPECIFIKACE

**Kapacita:** 4400 mAh**Napětí:** 11,1 V (10,8 V)**Technologie baterie:** Li-ion

### Nahrazuje baterie:

CP293550-01, CP293530-01, CP556150-01, CP556150-02

FMVNBP146, FMVNBP177, FMVNBP178, FPCBP145, FPCBP145AP, FPCBP146, FPCBP218, FPCBP218AP, FPCBP219, FPCBP219AP, FPCBP220, FPCBP220AP, FPCBP238, FPCBP238AP

S26391-F795-L300, S26391-F795-L400, S26391-F956-L100, S26391-F956-L200, S26391-F974-L50

FMVNBP190, FMVNBP198, FMVNBP199, FMVNBP210, FMVNBP242, FMVNGS7H6, FMVNGS7H8, FMVNGS7HE, FMVNS7H6, FMVNS7H6R, FMVNS7H6R2, FMVNS7H7, FMVNS7H7R, FMVNS7H7R2, FMVNS7H8, FMVNS7H8R2, FMVNS7HE, FMVNS7HER, FMVNS7HER2, FMVNS7HEZ, FMVNS7S6, FMVNS7S7, FMVNS7S8, FMVNS7SE, FMVNS7X6, FMVNS7X6R, FMVNS7X6R2, FMVNS7X7, FMVNS7X8, FMVNS7X8R2, FMVNS7XE, FMVNS7XER, FMVNS7XER2, FMVP74EB, FMVP74EN37, FMVP74EN38, FMVP74EW, FMVP75EN37, FMVP75EN38, FMVP75EN57, FMVP75EN58, FMVP75GN37, FMVP75GN38, FMVP75GN57, FMVP75GN58, FMVP75HN37, FMVP75HN38, FMVP75HN57, FMVP75HN58

FMVS54EB, FMVS54EN37, FMVS54EN38, FMVS54EN57, FMVS54EN58, FMVS54ER, FMVS54EW, FMVS54EWG, FMVS54EWTK, FMVS54GB, FMVS54GBG, FMVS54GMG, FMVS54GN37, FMVS54GN38, FMVS54GN57, FMVS54GN58, FMVS54GR, FMVS54GW, FMVS54GWG, FMVS54GWTK, FMVS54HB, FMVS54HN37, FMVS54HN38, FMVS54HN57, FMVS54HN58, FMVS54HR, FMVS54HW, FMVS54JL1R, FMVS54JL1W, FMVS54JL2R, FMVS54JL2W, FMVS54JL3R, FMVS54JL3W, FMVS54KD1R, FMVS54KD1W, FMVS54KD3R, FMVS54KD3W, FMVS54KD4R, FMVS54KD4W, FMVS54KD5R, FMVS54KD5W, FMVS54KD6R, FMVS54KD6W, FMVS54KDBW, FMVS54KDCR, FMVS54KDCW, FMVS54KR, FMVS54KRC, FMVS54KRG, FMVS54KW, FMVS54KWC, FMVS54KWG, FMVS56EBC, FMVS56ERC, FMVS56EWC, FMVS56GBC, FMVS56GRC, FMVS56GWC, FMVS56HBC, FMVS56HRC, FMVS56HWC

FMVS76, FMVS76E, FMVS76G, FMVS76GTK, FMVS76H, FMVS76HTK1, FMVS76HTK2, FMVS7EN5B7, FMVS7EN5B8, FMVS7EN5S7, FMVS7EN5S8, FMVS7EN7B7, FMVS7EN7B8, FMVS7EN7S7, FMVS7EN7S8, FMVS7GN5B7, FMVS7GN5B8, FMVS7GN5S7, FMVS7GN5S8, FMVS7GN7B7, FMVS7GN7B8, FMVS7GN7S7, FMVS7GN7S8, FMVS7HN5B7, FMVS7HN5B8, FMVS7HN5S7, FMVS7HN5S8, FMVS7HN7B7, FMVS7HN7B8, FMVS7HN7S7, FMVS7HN7S8, FPB0262, FPB0333S, FPC02422BK, FPC02424BK, FPC02425BK, FPC02426BK, FPC03481BK, FPC03483BK, FPC03484BK, FPC03485BK, FPC03486BK, FPC04653BK, FPC04654BK, FPC04655DK, FPC04689DK, FPC04689DM, FPC04705BK, FPC04712BK, FPC04719AK, FPC07309BK, FPCBP203, FPCBP281, FPCBP281AP, FPCBP282, FPCBP282AP, FPCBP283, FPCBP283AP, FPCBP325, FPCBP325AP, FPCBP519, MVS54GB

### Pro notebooky:

LifeBook AH52, AH54, AH56, AH572, AH77, AH78

LifeBook A561

LifeBook E741, E751, E752, E782, E8310

LifeBook LH700, LH772, L1010

LifeBook PH701, PH702, P701, P702, P770, P771, P772, P8110

LifeBook SH560, SH561, SH572, SH760, SH761, SH762, SH771, SH772, SH782, SH792

LifeBook S2210, S561, S6310, S6311, S710, S7110, S7111, S751, S752, S760, S761, S762, S782, S792

LifeBook TH550, T580